

Universelle Geräteaufnahme* Universal Device Mount*

Montagehinweise

Alle vom Motorrad gelösten Schrauben sind gemäß Herstellerangaben wieder zu montieren, oder mit von SW-MOTECH gelieferten Schrauben zu ersetzen. Falls nicht anderweitig definiert, diese Schrauben nach Tabelle anziehen.

M6 9,6 Nm

Gegebenenfalls Schrauben mit flüssiger Schraubensicherung einkleben.

Prüfen Sie nach 50 km alle Verbindungen auf festen Sitz.

SW-MOTECH GmbH & Co. KG
Ernteweg 8/10
35282 Rauschenberg
Germany

Tel. +49 (0) 64 25/8 16 8-00
Fax +49 (0) 64 25/8 16 8-10

info@sw-motech.com
www.sw-motech.com

* Geeignet für die folgenden GPS-Systeme:
RAM-Halter der GARMIN Street Pilot Serie 2610 – 2820
RAM-Halter GARMIN Quest Serie
TOMTOM Rider I & II
GARMIN Zumo
BAGS-CONNECTION PDA- und GPS-Bags

Das universelle AMPS-Loch-Muster ist kompatibel mit den meisten GPS-Systemen und Gerätehaltern.

* Applicable for the following GPS-systems:
RAM cradle for GARMIN Street Pilot serie 2610 – 2820
RAM cradle for GARMIN Quest series
TOMTOM Rider i & II
GARMIN Zumo
BAGS-CONNECTION PDA and GPS Bags

Universal AMPS hole pattern is compatible with the most devices or device holders.

Mounting Instructions

SW-MOTECH products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. SW Motech takes no responsibility for damages caused by improper installation.

All screws, bolts and nuts, including all replacement hardware provided by SW-MOTECH, should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M6 9,6 Nm

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts and nuts.

